



September 2005

Using the Internet with the Z300

Surf the web



Sony Ericsson

Using the Internet with the Z300

The Z300 has a browser that makes it possible for you to bring a modified Internet to your mobile phone. A wide range of fun and useful services is available, for example, news, entertainment, timetables, reservations, banking, e-commerce and wallpapers.

Note: Please visit www.SonyEricsson.com/support for additional information about using the Internet with the Z300.

Before you start

In order to use the Internet or browse via Internet services, the following are required:

- A phone subscription that supports data transmission.
- A correctly set up data account. A data account includes specific connection settings for access to a server at your service provider, for example via WAP or via e-mail. Settings may already be entered when you buy your phone or you can receive settings in a text message from your network operator or service provider or from www.SonyEricsson.com/support
- An Internet profile. User settings that allow Internet browsing are stored in an Internet profile. In most cases, you only need to use one profile to access the Internet. You set up and use additional Internet profiles, for example, when accessing secure Internet sites, such as a banking site or a corporate intranet. You then simply switch between profiles when you need to change the network connection.
- You may also have to register as an Internet user with your service provider or network operator.

Internet account and settings

General information

The settings you need may already be entered when you buy the phone, or you can enter them yourself in different ways:

- Receive them automatically in a text message by using the Phone setup for WAP at www.SonyEricsson.com/support.
- Receive them automatically in a text message from your service provider.
- Manually, by entering the settings directly in this guide “Enter settings manually” on page 4.

The first two ways of setting up Internet described above are recommended, if possible, since they take less time and effort than it takes to manually enter the settings.

Note: Internet settings are different for different service providers.

Receive settings using the Phone setup for WAP

You will find the Sony Ericsson WAP configurator at www.SonyEricsson.com/support. Select region and country, or Global support area. Select your phone model and choose Phone setup. To receive the correct Internet settings, you need to provide the following information:

- Country (the country your phone subscription is registered in)
- Mobile network
- Name of your Internet service provider
- Phone model

Follow the instructions on the screen. You will receive the auto configuration via SMS. When you receive the text message, simply press **YES** to install your new settings. You are now ready to start using Internet in your mobile phone.

Receive settings from your service provider

Check your service provider’s Web site for information, or contact their support desk and ask about automatic remote configuration of Internet.

If remote configuration is possible, they will send you the auto configuration via SMS. When you receive the text message, simply press **YES** to install your new settings.

Otherwise, if remote configuration is not possible, you can use the “wizard” in the phone to enter the relevant information.

You need to have the same information available when using the wizard as when entering the settings manually, described below.

To use the wizard for setting up Internet

1. ► **Internet services** ► **YES** ► **homepage** (for example **Sony Ericsson**) ► **YES**.
The wizard now starts if no Internet settings exist.
2. Enter and save settings when asked ► **YES** to confirm.

Enter settings manually

Some advanced settings that are described in the following texts are not mandatory. Please consult your network operator or service provider for more information.

To be able to enter these settings you must have the following information which you get from your service provider:

Using GPRS Data

- A subscription that supports GPRS Data
- APN (Access Point Name) address
- User id
- Password

Using GSM Data

- A subscription that supports GSM Data (**CSD** = Circuit Switched Data or **HSCSD** = High Speed Circuit Switched Data)
- Phone number
- User id
- Password

To create a data account manually

1. ► **Connectivity** ► **YES** ► **Data comm.** ► **YES** ► **Data accounts** ► **YES**.
2. ► **Add account?** ► **YES**.
3. Select account type, **GPRS data** or **GSM data** ► **YES**.
4. Enter a name for your new profile ► **YES**.
5. Enter the required information: **APN:** for GPRS data and **Phone no:** for GSM data. If necessary, enter **Username:** and **Password:** using the same procedure (service provider dependent).
6. ► **Save?** ► **YES** to save the settings.

To create Internet profile settings manually

1. Make sure you have a data account set up between your phone and the Internet server, as described above.
2. ► **Internet services** ► **YES** ► **Options** ► **YES** ► **Internet profiles** ► **YES**.
3. ► **Add profile?** ► **YES** and enter a name for the profile.
4. ► **Connect using:** ► **YES** and select the data account to be used.
5. Enter the IP address of the WAP gateway ► **YES**.
6. ► **Save?** ► **YES** to save the settings.

To enter an Internet address

With the Z300 you have access to Internet wherever you are. Use Internet services to find information that you need at just that moment, or for entertainment.

To enter a new Internet address

1. ► **Internet services** ► **YES** ► **Enter address** ► **YES** ► **New address?** ► **YES**.
2. Enter the address, for example "wap.SonyEricsson.com" ► **YES**. The phone now connects.

Using bookmarks

Bookmarks is a convenient way of handling Internet addresses. Use bookmarks to store addresses of your favourite Internet sites, so that you don't have to type them in time after time. You can store up to 25 bookmarks in your phone.

To add a new bookmark

1. ► **Internet services** ► **YES** ► **Bookmarks** ► **YES** ► **Add new?** ► **YES**.
2. Enter a title for your new bookmark, for example "Sony Ericsson". It is this title that will be shown in the display when you scroll between your different bookmarks.
Now enter the address of the Internet site that you want to create a bookmark for, for example "wap.SonyEricsson.com".
You do not need to type in the "http:/" prefix when entering the WAP site address. The phone automatically adds this prefix to the address when connecting.
3. The new bookmark is now stored in your phone.

To add a bookmark of the Internet site you are currently viewing

1. Press the option key ► **Bookmarks** ► **YES** ► **Add new?** ► **YES**. The phone now automatically fills in the title of the current Internet site. Optionally, you can rename the title, otherwise just press **YES** to accept.
2. The phone now automatically fills in the address of the current Internet site. Usually, there is no need to change this, just press **YES** to accept.
3. The new bookmark is now stored in your phone.

To connect to a Internet site stored in a bookmark

1. ► **Internet services** ► **Bookmarks** ► **YES**.
2. Scroll to the bookmark you want to connect to ► **YES**. The phone now connects.

This Getting Started guide is published by:

Sony Ericsson Mobile Communications AB,
SE-221 88 Lund, Sweden

Phone: +46 46 19 40 00

Fax: +46 46 19 41 00

www.SonyEricsson.com

© Sony Ericsson Mobile Communications AB,
2005. All rights reserved. You are hereby granted
a license to download and/or print a copy of this
document.

Any rights not expressly granted herein are
reserved.

First edition (September 2005)

Publication number: EN/LZT 108 8090 R1A

This document is published by Sony Ericsson
Mobile Communications AB, without any warranty*.
Improvements and changes to this text necessitated
by typographical errors, inaccuracies of current
information or improvements to programs and/or
equipment, may be made by Sony Ericsson
Mobile Communications AB at any time and
without notice. Such changes will, however, be
incorporated into new editions of this document.
Printed versions are to be regarded as temporary
reference copies only.

*All implied warranties, including without limitation
the implied warranties of merchantability or fitness
for a particular purpose, are excluded. In no event
shall Sony Ericsson or its licensors be liable for
incidental or consequential damages of any nature,
including but not limited to lost profits or commercial
loss, arising out of the use of the information in this
document.