



July 2007

# Video calls

---

*Keep in touch using voice and video*



Sony Ericsson

# Contents









Introduction .....	2
Before you start .....	2
Making a video call .....	3
Answering and ending a video call .....	3
Zooming .....	4
Sharing pictures during a video call .....	4
Video call options .....	4
Trademarks and acknowledgements .....	5

# Introduction

---

## Instruction symbols

The following instruction symbols may appear in this Getting started guide:

	Tip
	Note Some icons in user documentation may differ from those below.
	Indicates that a service or function is network- or subscription-dependent. Contact your network operator for details.
>	Use the selection keys or the navigation key to scroll and select.
	Navigation key.
	Press the navigation key up.
	Press the navigation key down.
	Press the navigation key to the left.
	Press the navigation key to the right.

With the speed of 3G (UMTS) you can keep in touch using voice and video. During the call, you see the person you are talking to on your screen and the person can see you.

! Some phone keys and functionality may differ from the instructions in this document.


## Before you start

---

Before you start making a video call you need:

- a 3G (UMTS) phone subscription and a SIM card which supports 3G (UMTS).
- to make sure that you are within coverage of a 3G (UMTS) network.

The person you are calling must also have a 3G (UMTS) phone which supports video calling, and the conditions above apply to the person you are calling as well.

! 3G (UMTS) service is available when the 3G icon  appears in the status bar.

# Making a video call

---

There are several ways of making a video call:

- from standby
- from contacts
- from the call list
- from a message
- from within the video call application.

## *To make a call from standby*

1. Enter phone number (international prefix and area code if applicable).
2. Select **Options** > **Make video call**.

## *To make a call from contacts*

1. From standby select **Contacts** and scroll to a contact to call.
2. Select **Options** > **Make video call**.

## *To make a call from the call list*

1. From standby select **Menu** > **Calls** and select a tab.
2. Scroll to the name or number you want to call.
3. Select **Options** > **Make video call**.

## *To make a call from a message*

1. From standby select **Menu** > **Messaging** and select a folder.
2. Open a message from the person you want to call.
3. Select **Options** > **Use** > **Video call**.

## *To make a call from within the video call application*

1. Select **Options**.
2. Select **Call list** > **Contacts** and the phone number you want to call, or enter a phone number.
3. Select **Call**.

# Answering and ending a video call

---

## *To answer an incoming video call*

- Press .



## *To end a video call*

- Press .

## Zooming

---

### *To use the zoom with an outgoing video call*

From the video call menu, press  to zoom in and press  to zoom out.


## Sharing pictures during a video call

---

Share a picture with the person you are calling.

! Not all phones have this function.




### *To share pictures during a call*

1. Press  to select the pictures tab.
2. Scroll to a picture and select **Share**.

## Video call options

---

Several options are available to optimise a video call. From within the video call application select **Options** and select from the list:

- **Switch camera** – to switch between the main camera and the video call camera. Use the main camera to show a fullscreen image of your surroundings to the recipient.
- **Sound** – options during a video call.
  - **Speaker on/Speaker off** – turn the incoming sound off or on.
  - **Microphone on/Microphone off** – to mute the microphone during a video call. You can also press and hold  as a shortcut.
  - **Transfer sound** – have the incoming sound transferred to handsfree equipment via Bluetooth™ wireless technology.
- **Camera** – options.
  - **Take picture** – you can take a picture from the large video window only when it contains live video during an active call.
  - **Layout** – choose the size of the outgoing video call window and incoming video call window. You can also hide your self-portrait. This does not affect what the other person sees.
  - **Brightness** – adjust the brightness of the outgoing video image. Press  or  to decrease or increase the brightness level.
  - **Night mode on/Night mode off** – use when lighting conditions are poor. This affects the outgoing video image. A half moon icon appears close to the outgoing video screen when the night mode is on.
- **Call list** – make a video call from call list. You can select a contact or enter a number.

- **Settings** – answering options.
  - **Answer showing...** – set the video call camera to be on or off when you answer a video call.

💡 If you answer with the video call camera turned off.

- **Camera off pic** – set a picture to show to the recipient when the camera is off.
- **Video call sound** – select if microphone, speaker, or both should be on or off.
- **Video quality** – select a picture quality for video calls. Changes do not take effect during an ongoing call. Select **Motion quality** for a better flow of images. Select **Standard** for standard viewing. Select **Picture quality** for detailed images.

## Trademarks and acknowledgements

---

This Getting started guide is published by:

Sony Ericsson Mobile Communications AB,  
SE-221 88 Lund, Sweden

Phone: +46 46 19 40 00

Fax: +46 46 19 41 00

[www.sonyericsson.com](http://www.sonyericsson.com)

© Sony Ericsson Mobile Communications AB, 2007. All rights reserved. You are hereby granted a license to download and/or print a copy of this document.

Any rights not expressly granted herein are reserved.

First edition (July 2007)

Publication number: 1202-4885.1

This document is published by Sony Ericsson Mobile Communications AB, without any warranty\*. Improvements and changes to this text necessitated by typographical errors, inaccuracies of current information or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this document. Printed versions are to be regarded as temporary reference copies only.

\*All implied warranties, including without limitation the implied warranties of merchantability or fitness for a particular purpose, are excluded. In no event shall Sony Ericsson or its licensors be liable for incidental or consequential damages of any nature, including but not limited to lost profits or commercial loss, arising out of the use of the information in this document.